

A10 Series Problem Overshoot

Canaan Creative .,Ltd

Overview

Thank you for choosing our products. In order to ensure that you can fully understand and install this product, please read the manual carefully. After reading, please keep it in a safe place for future reference.

Safety regulation

Warning: In order to prevent accidents that threaten human safety such as equipment damage, fall, electric shock, fire, etc., please install and use it strictly in accordance with the instructions. You cannot modify the equipment and replace parts by yourself.

- Do not use a power supply that exceeds the rated voltage range.
- Do not place the device in an unstable location.
- When inspecting and repairing equipment, please entrust professional operations.
- When the equipment is abnormal, please cut off the power quickly and contact the after-sales service.

Hardware Connection

Connect the power supply and product as shown below



Power connection

Fix the adapter board to the machine with six M3 * 4 screws as shown in the figure. Push the power supply into the card slot as shown in the figure .



Use twelve M4 * 8 screws to connect the output conductive copper bar as shown in the figure below to connect the power supply to the machine.




Insert the power 6pin plug into the 6pin socket of the machine as shown below.



Serial Connection

Each machine is equipped with two network ports, which can be connected in series by A network cable (up to 12) .

An example is as follows. Network cable A is connected to a switch (or router). The first machine and the second machine are connected in series with a network cable B. The second machine and the third machine are connected in series with a network cable C.



Button and Indication LED



Button

RESET: System reset button, system reset will not affect internet concatenation.

FUNC: Function keys, which can be used to restore the factory configuration, enter configuration mode, switch lighting status during operation, etc.

Indication LED

- The indicator light flashes **red** several times after power-on.
- After the device starts, the indicator lights up in **white** for about three seconds. During this period, pressing the FUNC key will enter the configuration mode.
- Normal mining condition, indication LED is **Green**.
- System initialization period, LED is **yellow**.
- System overheat condition, LED is **RED**.
- During system operation, through FMS software or manually pressing the FUNC key, the indicator light is always white, press it again to restore the original color
- Restore factory settings: When powering on (before the indicator flashes red), press the FUNC function key for five seconds, until the white light flashes to indicate success, then press RESET or disconnect the power to restart

Work mode

This device has two working modes: "normal mode" and "configuration mode"

Normal mode

Normal working mode. The device runs in this mode for most of the life cycle of the device. In this mode, the network can use DHCP (dynamic acquisition) or static IP.


Configuration mode

During the white light after startup (about three seconds), press the FUNC key, the device will enter this mode

.In this mode, the IP address is static (address: 192.168.168.168, subnet mask: 255.255.255.0). You can access the built-in Web service of the device through a PC browser, and then configure the network, mining pool, password, and other information.

Set the PC to a static IP address: 192.168.168.100 (or any other non-conflicting address on the same network segment), subnet mask: 255.255.255.0, and connect to the same network

with the device (under the same switch or router, or the PC and Device network cable is directly connected)



1. Click , Open the Network and Internet settings.

2. Change adapter options, disable WLAN, enable Ethernet.


You can use a browser to access <http://192.168.168.168/> to configure the device (modify a static IP, etc.). After the configuration of the device is completed, it needs to be restarted to take effect. You can click Reboot on the left side of the console or restart it manually. Do n't forget to switch the network connection so that your device cannot access the internet. Revisit the modified IP address using a browser. If the indicator is green, the operation is correct.

System setting

Access the device's built-in web service through a browser, and log in to the device console

User Log

Default user: root, Default password: root, After logging in, you will see the Overview page.



Network setting

Click Network on the left side of the console, it can be set to DHCP (Dynamic Acquisition) or Static IP (Static).

Note: After saving the network settings, you must restart to take effect. You can click Reboot on the left side of the console, or press the RESET button to restart, or you can disconnect the power and restart the power.

Pool Setting

The figure below is the factory default setting. Work Mode can be selected from Normal Mode (low power consumption mode) or High Performance (high power consumption mode). When using High Performance mode, please pay attention to the use of higher power output power supply Socket to prevent damage to the hardware.

Note: After the mining pool configuration is saved, it must be restarted to take effect. You can click Reboot on the left side of the console, or press the RESET button to restart, or you can disconnect the power and restart the power.

The screenshot shows the 'Avalon Miner' web interface. On the left is a dark sidebar with a menu: '> Overview', '> Pool' (highlighted in red), '> Network', '> System' (with sub-items '>> Administrator', '>> Logout', and '>> Reboot'), '> Upgrade', and '> Log'. At the bottom of the sidebar is the text 'Canaan Creative Co., Ltd.' with a left-pointing arrow. The main area is titled 'Pool Configure' and contains three input fields: 'Pool' with the value 'stratum+tcp://btc.ss.poolin.com:443', 'Worker' with 'cctrix.001', and 'Password' with '123'. Below these is the 'Advanced Configure' section with a 'Work Mode' dropdown menu set to 'Normal Mode'. A 'Save' button is located at the bottom right of the configuration area.

User Password


Default Username: **root**, Default Password: **root**

Click Administrator on the left side of the console to set a new password and save

Firmware Upgrade

The file format of the upgrade package for this device is *.aup, which can be downloaded from the official website or contact customer service. The firmware upgrade of this device can be performed by FMS software

The firmware upgrade of this device can be performed by FMS software.



Reset to Default setting

When powering on (before the indicator flashes red), press and hold (Five to ten seconds) the FUNC key, and the system will automatically clear the saved configuration, including: network, mining pool, password and other information. After the configuration is cleared, the indicator blinks frequently white, indicating that the configuration restoration was successful. After releasing the FUNC key, press the RESET button to restart, or disconnect the power supply and power on again, the system will work with the default factory configuration.

Device Warranty

During use, you may encounter equipment that does not work properly due to loose connection and abnormal damage of the device wire. You can troubleshoot and troubleshoot it yourself. If the device is damaged and under warranty, you can contact our after-sales personnel for a quick repair.

This product provides a 180-day warranty from the time the user receives the goods, but the following conditions will void the warranty:

- Any physical damage caused by dismantling the device or other reasons (including but not limited to: broken, chipped, missing corner, missing components, etc.)
- Damage caused by lightning strikes, voltage surges, etc.
- Circuit board is burnt or chip is burned
- Damage caused by water ingress or immersion
- Circuit boards are wet and corroded

- Warranty period

Malfunction self-examination

Boot Failure

1、Failure Phenomenon

Miner fan does not turn on or LED light does not turn on after boot.

2、Possible Cause

The fan wiring of the mining machine is loosened, the power supply line of the control board of the mining machine is disconnected, the AC power input is not connected, the power module is broken, the control board is broken, and the power output is short-circuit protected.

3、Inspection and repair method

- Power on the whole machine, turn on the power switch of the miner, and plug in the network cable connected to the switch (or router). Check that the network port link light is blinking. If the network port light is off, the MM control board is out of power. You need to check the power cable connection, replace the power supply, or check whether there is a short circuit in the power output. 。
- If the network port light is on, but the MM control board LED is off, you need to replace the MM control board.
- If the MM control board LED is on but the fan does not rotate, check the fan cable or replace the fan.

Can' t Mining

1、Failure Phenomenon

- The mine pool cannot be connected for a long time (more than 5 minutes) after booting up (the miner lights up yellow for a long time, does not turn green, and has no computing power).
- Can be connected to the mining pool after power on (miner's LED light is green), but no computing power.

2、Possible Cause


- POOL configuration fault.
- Network configuration fault.
- Miner can't go outside network.
- Miner power don't have main output(fault wire connection, overload,short or broken).
- Miner hashboard can't work.
- Miner overhot Protection.

3、Check and repair


- If you cannot use the PC to connect to the miner through the network, you can try to

restore the factory settings after confirming that the network environment is normal, the network cable is firmly connected, and the miner is turned on normally. For the method of restoring factory settings, see Appendix 1.

- Check the current firmware version of the mining machine. It is recommended to use FMS to update to the latest version. For the upgrade method, see Appendix III.
- Check hashboard status.
- Click Overview to check the working status shown in ② in the figure below. Normally, it should be In Work. If OverHot indicates overheating shutdown, you need to check the fan and ambient temperature as follows.
- Check the number of Hash Boards shown in ③ in the figure below. For 104x series, the value should be 2. If the value is 1, you need to contact our after-sales personnel to deal with it. If it is 0, you need to check the power status according to the following.



1. Check Power, temperature, network status, fan status.
Click Log on the left side .see below:



Check the following fields in the right interface:

- NETFAIL (As shown in ②) : Recorded the time of disconnection from the mining pool (if it has not been disconnected or has never been connected to the mining pool, it is all 0 here). In this record, the odd-numbered items (items 1, 3, and 5) are the time when the mine pool was disconnected, and the even-numbered items (items 2, 4, and 6) are the times when the connection to the mine pool is restored. If only the odd-

numbered items have data and the even-numbered items are 0, it indicates that the connection to the mining pool is currently disconnected and has not been restored (usually because the server at the mining pool end is overstressed and disconnected. If it occurs frequently for a long time, you can replace other mining pools to dig mine).SYSTEMSTATU: Records the current working status, which is normally In Work (as shown in ③). Among them, Hash Board (shown as ④): the number of HASH boards in operation, for 104x models, it should be 2. If it is 1, you need to contact the after-sales service. If it is 0, you need to further check the status of the power supply.

- Temp is ambient temperature, not exceed 35°C。
- TMax is highest ASIC IC temperature, not exceed 85°C。
- TAvg is average ASIC temperature.
- If you see any of the above temperature items are too high (Temp exceeds 35, Tmax exceeds 85, TAvg exceeds 68), you need to check the fan speed (as shown in ⑥).


For 104x models, only Fan1 and Fan2. If the fan speed is normal, you need to reduce the indoor temperature and ensure good ventilation around the miner.

- Vo (shown as ⑦) is the average chip voltage, which is normally 32x。
- PS (shown as ⑧) is the power state. The meaning of items 1-6 is as follows:
 - Item 1: Error code. Normal is 0. Other values indicate power failure or output short circuit.
 - Item 2: Voltage supplied to the control board. Normal is 12xx.
 - Item 3: Voltage (unit: 10mV) for the hash board (normally between 1200 and 1400).
 - Item 4: The current output by the power supply to the hash board, specifically related to the output power and voltage.
 - Item 5: The output power from the power supply to the hash board. For 104x models, the normal value is between 1800-2500 (in W).
 - Item 6: The expected output voltage from the power supply to the hash board, which is configured by the control board.

If the 6 parameters of the power supply PS field are all 0, it means that the control board cannot communicate with the power supply. Please check the line connection. If the connection is correct, the power supply needs to be replaced.

2. Check whether the configuration of the mining pool, miner, and miner passwords is correct


In the background of the mining machine, click Pool on the left side, check the configuration of Pool, Worker, Password, and finally click the Save button to save the settings.



3. Check Network setting

- Click NetWork on the left. The default configuration is DHCP mode. If all data here is empty, press F5 to refresh the page.
- If you use a static IP, pay attention to the DNS configuration. Incorrect DNS configuration will cause the mining machine to be unable to access the mining pool.
- The DNS address commonly used in China is 114.114.114.114, and the DNS address commonly used outside China is 8.8.8.8.

Notice: After modifying the configuration, you need to click the save button to save the configuration.



Appendix Restore the default setting SOP

- Restore default setting method 1

Step	Remark
Makesure the miner is power off.	

Press the func button and keep it pressed	
Power on the miner	Note that you need to keep the func key pressed.
Keep the func pressed until the white LED of the miner flashes.	

- Restore default setting 2


Step	Remark
Miner can't connect to power.	
Press func button and keep pressing status.	
Press reset and release.	Note that you need to keep the func key pressed.
Keep the func pressed until the white LED of the miner flashes.	

Appendix 2 Firmware version Check

2 method to check the firmware version:


View version in background:

Click on the left column Overview, you can see the firmware version number marked by ② in the figure below.




Use FMS to check:

Directly check the rightmost column of the miner list in FMS, as shown in the following figure ①.




Appendix 3 FMS Operation method for batch upgrade of mining machine firmware


Start FMS, select the corresponding miner in the main interface, and click the Upgrade button, as shown below:



In the dialog box that appears, select the firmware file (.aup) to be upgraded and click open. As shown below:



There will be progress prompts during the update process:



At the end of the update, there will be a prompt. If all are successful, it will be All upgrades were successful, otherwise all IP addresses that failed to be upgraded will be listed.

For the miners that failed to upgrade, you can select them according to the IP and click the button **Restart** to restart them. Wait 3 minutes and try to upgrade these miners again.

APPENDIX 4 Log Page main parameter

Field	Name	Remark
Elapsed	Total running time after the miner starts (unit: second)	

Ver	Miner firmware version	
DNA	The world's only mining machine ID.	
NETFAIL	After the mining pool is successfully connected, the time to disconnect from the mining pool and the time to resume the connection.	The odd numbered items (items 1, 3, and 5) are the time to disconnect from the mining pool, and the even numbered items (items 2, 4, and 6) are the times to restore the connection to the mining pool. The time is in seconds, and the startup time of the miner is the 0th second.
SYSTEMSTATU	Current system status, including working status and number of HASH boards in operation.	
DH	The average calculation error rate. Normal value 0.6-1.6% 。	
Temp	Ambient temperature。	
TMax	Maximum chip temperature	
TAvg	Average chip temperature	
Fan1	Fan 1 rotate speed	
Fan2	Fan 2 rotate speed	
FanR	Fan rotate Percentage	
Vo	Average chip voltage	
PS	Power state	The meaning of items 1-6 is as follows: Item 1: Error code. Normal is 0. Other values indicate power failure or output short circuit. Item 2: Voltage supplied to the control board. Normal is 12xx. Item 3: The voltage supplied to the hash board (HASH board) is normally between 1200 and 1400 (unit 10mV). Item 4: The current output by the power supply to the hash board, which is specifically related to

		<p>the output power and voltage.</p> <p>Item 5: The output power from the power supply to the hash board. For 104x models, the normal value is between 1800-2500 (in W).</p> <p>Item 6: The expected output voltage from the power supply to the hash board. This voltage is configured by the control board.</p> <p>If the six parameters of the power PS field are all 0, the control board cannot communicate with the power.</p>
GHSmm	Theoretical computing power in GH / s.	Note: The actual computing power is the value obtained by subtracting DH (calculation error rate) from the theoretical computing power.
GHSavg	1 hour average computing power	The 1-hour average computing power calculated based on the actually submitted work is the closest to the 24-hour average computing power at the mining pool end.
Freq	Equivalent frequency	The chip works at different frequency points, and the equivalent frequency is the comprehensive equivalent frequency of the whole machine.
Led	White LED light status	When you need to find a specific one among many miners, use the API to light up the white LED of the miner. Here is the state of whether the white LED light is on, 1 means

		it is on, 0 means it is off.
MGHS	Computing power of a single computing board in GH / s	
MTmax	Maximum chip temperature in a single hash board.	
MTavg	The average chip temperature of a single hash board.	
TA	Total number of ASIC chips	
SF0	Frequency distribution status of hash board 0.	For example, SF0 [500 525 550 575] means that frequency point 1 is 500MHz and frequency point 4 is 575MHz.
SF1	Frequency distribution state of the hash board 1.	
PVT_T0	List of the temperature of all chips on hash board 0.	
PVT_T1	List of the temperature of all chips on hash board 1.	
PVT_V0	List of the voltage of all chips on hash board 0.	
PVT_V1	List of the voltage of all chips on hash board 1.	

APPENDIX 5 LED status

1. LED lamp status flow process under normal startup:

Status	Red LED Blink	White LED on	Yellow LED On	Green LED On
Duration	1s	1s	Approximately 20-30s	Long time

2. LED status condition

LED Status	Description
Off state	The firmware is not running. (Possibly no power input).
Flashing red	Blinks for 1s before system startup.
White LED on	Lights up for 1s before system startup, or uses API control to light up
White LED Blink	The system enters test mode. (Or restore the state after the factory setting operation, you need to

	release the func button and restart to make the master control enter the normal working state.)
Yellow Light on	The system is started but not connected to the mining pool. Or prompt when switching to the frequency reduction mode.
Green LED on	The system has been started and connected to the mining pool.